



Pipetting needle for slide work area kit (12.110)

(Using for viscous buffers)



Change the needle for the slide work area like the picture below:



Please connect the needle to the red channel and use the plastic screw to block the green channel.

Information: It might be necessary to change the pipetting speed for the viscous buffers to 2 ml per minute.