

## **New measurement system for PM and ultrafine particles**

J. Spielvogel, M. Weiß

Palas GmbH, Karlsruhe, 76229, Germany

Keywords: aerosol instrumentation, particle sizer, nanoparticles, number concentration

Presenting author email: spielvogel@palas.de

According to a recently published report by the European Environment Agency about one third of Europe's population in cities is exposed to excessive concentrations of particulate matter (PM). These people are also exposed to high concentrations of ultrafine particles caused for example by traffic and heating.

We will present a new measurement system that can measure the number concentration and size distribution of airborne particles from 8 nm to 18  $\mu\text{m}$ . In addition, it also reports simultaneously different PM-fractions such as PM-1, PM-2.5 and PM-10. With a time resolution of 5 minutes it can further capture dynamic changes in the aerosol distribution caused for example by rush hour traffic in the morning and afternoon.

The measurement system combines a scanning mobility particle sizer in which the working fluid to condense the particles can be chosen to be water or butanol with a continuous ambient air quality monitoring system. In the latter a polychromatic light source is used to illuminate aerosol particles as they pass through the optical sensing volume. The scattered light of each individual particle is then detected with a photomultiplier.

The system is operated through a touchscreen with intuitive graphical user interface and integrated data logger. Data can be easily viewed on the screen or later extensively evaluated through the included software.

We will show and discuss selected measurements in which the additional information of particle size distribution helps to interpret the PM-data and also facilitates source apportionment.